

Congratulations on the purchase of your Show 'N' Write™.

Owner's Manual

Includes:

- Parts List
- Assembly Instructions
- Disassembly Instructions
- Storage Instructions
- Care Instructions
- Warranty Information


Please read all of the information carefully and contact your distributor or supplier with any issues.



Parts List

Important: Before you begin please count and inspect all pieces.

- 1 - Panel Display (A)
- 1 - Header Display (B)
- 1 - Header Graphic (C)
- 2 - Header Connector (D)
- 1 - Soft Carry Case (E)



Assembly Instructions




Step 1

Lay header (B) flat on table. Place header graphic (C) Velcro™ side down, on Velcro™ receptive header (B) of the display.



Step 2


Unfold side panels to approximately 30° angles and set on tabletop.



Step 3

Line up the connector (D) with the groove on the edge of the center panel (A). Push down until the connector is sitting on top of the panel (A). Repeat on the other side of the center panel.

Assembly Instructions (cont.)



Step 4

Line up the groove on the edge of the header (B) with both connectors (D). Slide header (B) down until it rests on top of the center panel (A).

Disassembly Instructions



Step 1

Remove header (B) and connectors (D) from display (A). Fold display (A) together in Z-shaped pattern, and lay it flat.

Storage Instructions



Place and store all components in soft carry case (E) and store in a cool dry place.

Care Instructions

Spot clean with damp cloth.

Warranty Information

All products are designed to provide the user with a cost-effective and durable product. Standard warranty is a 'one year parts and labor' warranty which warrants product against defects in material and workmanship. It does not cover damage due to accidents, abuse, or normal wear and tear. Products found to be defective will be replaced or repaired at factory's discretion.